

EL-BL-10-02 Set Up Instructions

Step 1: Connect poles by pressing and pushing together, then connect corner sections to straight sections with matching shape symbols.




Step 4: Unzip print and lay image face down. Slide print onto the frame like a pillow case.

(lights face down)




Step 8: Collect cables together and close zipper. Plug power supply into electrical unit and turn on to complete.


Step 2: Take out the LED Lights and gently unroll on the ground with lights face down. WARNING! Do not drag lights across ground or it could break the LED lights.



Step 5: Unzip pocket on black fabric for more stretch. Pull graphic over bottom edge and pinch zipper to together to zip closed.




Step 3: Attach each LED Light Array to top and bottom of frame.



Pull extra cable leash at bottom to secure each LED Light Array into place.





Step 6: Connect the feet by inserting into the bottom holes of frame and pressing firmly. Lift frame into upright position.



NOTE: If you can see the lights and the print is not evenly diffused:


- 1. Check that the display is level and not leaning forward.
- 2. The graphic is fully zipped on bottom and under tension.

Step 7: Find cable ends and pull through grommet holes. Connect each power cable to a power supply. WARNING! Only connect one light array to each power supply.




- 3. The lights are hooked to the back of frame and the printing is on the opposite front side of frame.
- 4. Make sure light array has been fully tensioned with the extra cable leash (Step 3) and not loose.

Step 1: Assemble straight poles by pressing and pushing together.







Step 4: Insert feet into base to complete assembled frame shown.




Step 5: Unzip print and lay image face up. Slide print onto frame like a pillow case.



Step 6: Zip the edge of graphic beyond the center point as shown to hold the center pole in place. Zip the remaining side and bottom to meet at the corner.



Step 7: Complete.







LIGHTS:
(OPTIONAL) Position as desired
and tighten knob to hold in place.
WARNING! Over tightening may
cause damage to fabric image.




EL-BL-10-02 2951[116.2"]

Step 1: Assemble each section of the frame by pressing and pushing poles together.


Step 2: Insert correct number of cross bar support poles based on Step 4.

Step 3: Connect all corner sections to straight sections of the frame by matching shape symbols on pipes.


Step 4: Unzip print and lay image face up. Slide print onto frame like a pillow case.




Step 5: Insert feet into the holes at the bottom of display.




Step 6: Add shelves to frame. Position and level shelves on frame before tightening clamps down with hex tool.



Step 7: Complete.







ATTACHMENT TO WALL:

Position waterfall as desired on support wall before tightening clamps down with hex tool.

