

FabLite Essential FL-E-20-05 Straight

FL-E-20-05-S

FabLite 20' Straight backwall incorporates a sleek, straight aluminum frame with a zipper pillowcase fabric graphic to create a sharp, bold backwall that clearly conveys who you are and what you do. Print on just one side or both sides of the graphic to maximize your message and brand exposure.



features and benefits:

- State-of-the-art 30mm aluminum tubing with heavy duty internal spigot connectors
- Easy to store and ship
- Quick to set up
- Kit includes: one frame, one dye-sublimated zipper pillowcase graphic, and 2 wheeled molded storage cases
- Lifetime hardware warranty against manufacturer defects

dimensions:

Hardware

Graphic

Assembled unit:
227.94" w x 92.33" h x 25.59" d
5790mm(w) x 2346mm(h) x 650mm(d)

Refer to related graphic template for more information.

Approximate weight (includes graphic):
75 lbs / 34 kg

Shipping

additional information:

Packing case(s):
2 OCE

Graphic material:
Dye-sublimated zipper pillowcase fabric

OCE: Expandable case length (l) may vary
40" - 66" l x 18" h x 18" d
1016mm-1677mm(l) x 458mm(h) x 458mm(d)

Optional accessories:
Lumina 8-50 watt halogen lighting,
literature pocket, stand-off literature rack,
stand-off graphic shelf, graphic header,
larger freight cases

Approximate shipping weight (with case):
129 lbs / 59 kg

Included In Your Kit

Tools, Components, Connectors, Tubes & Graphics



5MM ALLEN-T x1



LN114-SCRW x2



PLT-BP-LN114-S2-650 x2



TC-30-S x3



ES50 x2



ES50-2W x2



ES50-I-ES50-C-ASY x2




TC-30-D-ES50-S-ASY x5




TC-30-D-ES50-S-ASY-2 x1




WS20-01-T1 x8



WS20-01-T2 x4




WS20-01-T3 x6



FMLT-WS20-01-G x1


Exploded Diagram

FL-E-20-05-S




Labeling Diagram

FL-E-20-05-S




Connection Methods

Connection Method 1: ES50-2W Spigot Connectors




Compress one unlocked end of the connector and slide it through one tube end. Compress the other end of the connector and slide the second tube on. Lock both screws carefully using your allen key tool. Be sure to lock securely, but do not over tighten.

Connection Method 2: ES50



For spigot connections, compress the unlocked connector and slide into the tube lock access hole. Lock both screws carefully using your allen key tool. Be sure to lock securely, but do not over tighten. Do not force the connection and be careful with the tube edges, they may be sharp. To disassemble, unlocked connector press the snap button and pull apart.

Connection Method 3: TC-30-S



Take the plastic connector and make sure the snap buttons are in proper position for the frame tube holes. Simply press the snap button with your thumb and carefully slide the tube onto the connector. The snap button should pop through. Some twisting may be necessary to assure the snap button has popped all the way through the tube hole. Do not force the connection and be careful with the tube edges, they may be sharp.

Connection Method 4: Stabilizing Plate



First, loosen the set screw that is on the PLT-BP-LN114, then attach the base plate with the LN114-SCRW insert. Once the base plate is in the desired position, fasten the set screw to hold the insert in place.

Connection Methods

Connection Method 5: ES50-2W



Compress one unlocked end of the connector and slide it through one tube end. Compress the other end of the connector and slide the second tube on. Lock both screws carefully using your allen key tool. Be sure to lock securely, but do not over tighten.

Connection Method 6: 30-D-ES50



For connections, Compress one unlocked end of the connector and slide it through one tube end. Compress the other end of the connector and slide the second tube on. Next, Slide 30mm tube down onto TC-30-D-ES50-S-ASY (pictured in the "included in your kit" section above), til snap into place.



Kit Assembly

Step by Step

Step 1.


Gather the components to build the frame. Use the Exploded View and the Labeling Diagram for part labels.

Reference Connection Method(s) 1, 2 and 3 for more details.



Step 2.



Pull the pillowcase graphic over the frame and zipper it closed at the bottom.



Step 3.

Gather the components to stand the frame. Use the Exploded View for part labels.

Reference Connection Method(s) 4 for more details.



Step 4.


Setup is complete.



Stand-off Counter with Shelves

FLA-07

FabLite® accents enhance the functionality of any 10ft or 20ft backwall and add more real estate for messaging too! You are sure to find the accent that best fits your needs with monitor supports, literature pockets, shelves, tables, counters and more. Side tables and graphic headers are also available.



features and benefits:

- Premium aluminum tube frame with snap button and spigot assembly
- Easy to store and ship
- Quick to set up
- Kit Includes: Wood shelves
- Lifetime limited hardware warranty against manufacturer defects

dimensions:

Hardware

Assembled unit:
36" w x 92.5" h x 20.75" d
915mm(w) x 2350mm(h) x 527mm(d)

Approximate weight with cases:
71 lbs / 32 kgs

Shipping

Packing case(s):
1 OCH2 Case

Shipping dimensions:
OCH2:
52" l x 30" w x 14" h
1321mm(w) x 762mm(h) x 356mm(d)

Approximate total shipping weight
(includes cases & graphics):
72 lbs / 33kgs

Wood Finish Options



Included In Your Kit

Tools, Components, & Connectors



ALLEN KEY SET x1



ES30 x6



TC-30-A-TC-30-B-ASY x4



SHLF-FMLT-WL07-1 x2



CT-FMLT-WL07-1 x1

Graphics



FLA-07-G x1

Included In Your Kit

Tubes



FMLT-WL07-T1 x4



FMLT-WL07-T2 x4



FMLT-WL07-T3 x4



FMLT-WL07-T4 x1



FMLT-WL07-T5 x1



FMLT-WL07-T6 x2




FMLT-WL07-T7 x1




FMLT-WL07-T8 x1



FMLT-WL07-T9 x1



FMLT-WL07-T10 x1




FMLT-WL07-T11 x1



FMLT-WL07-T12 x1


Exploded View

FLA-07



Labeling Diagram


FLA-07



Connection Methods


FabLite® structures use a number of different yet simple connection methods. Your kit will include one or more of the connection methods shown below. Steps within the Kit Assembly will reference a specific method for each connection point.

Connection Method 1: ES30 / ES50 / ES75



Compress the unlocked connector and slide one tube onto each end. Lock both screws carefully using your allen key tool. Be sure to lock securely, but do not overtighten.

Connection Method 2: Snap Buttons & Swage



Locate the snap button on the connector or swage tube. Locate the hole on the corresponding tube. Press the snap button with your thumb and slide the tube and connector together so that the snap button snaps fully into the lock hole. To disassemble, press the snap button and pull apart.

Connection Method 3: ES30-90B / ES30-I / ES30-C



Compress one unlocked end of the connector and slide it through one tube end. Compress the other end of the connector and slide the second tube on. Lock both screws carefully using your allen key tool. Be sure to lock securely, but do not overtighten.

Connection Method 4: Tube Clamps



Be sure to fully assemble all frames before using clamps. With the clamp unlocked, place one tube of the first frame into the mouth of the clamp. Place the second tube (if applicable) into the second mouth of the clamp. With both frame's tubes in the clamp, be sure to lock securely, but do not overtighten.

Kit Assembly

Step by Step

Step 1.


Gather the components necessary for assembling Frame A. Begin by only assembling the lower portion. Assemble in order according to the Labeling Diagram.

Please reference Connection Method 2 for more details.



Step 2.

Apply the FLA-07-G graphic using the preapplied velcro.



Step 3.

Locate your CT-FMLT-WL07-1 counter top. Install with the long tubes through the counter top holes.



Step 4.

Assemble the remainder of Frame A. Assemble in order according to the Labeling Diagram.

Please reference Connection Method 1 for more details.



Kit Assembly

Step by Step

Step 5.


Unite the top half of Frame A with its bottom portion. Be sure to connect in the correct orientation.

Please reference Connection Method 2 for more details.



Step 6.

Locate your shelves. Install by allowing the plates on the tubes to fit into the routes beneath the shelf. Lock into place using the provided thumbscrews included with the shelf.



Step 7.

Clamp your ladder assembly to your backwall utilizing the preinstalled clamps.

Please reference Connection Method 4 for more details.

